

## **Pacbio Reads**

### **Locations:**

Sample location:

Pacbio location: /storage/datasets/Tetrahymena\_thermophila/SRX2635099/fastq

Tlr reference:

/storage/datasets/Tetrahymena\_thermophila/analyses/virus/data/Tlr\_complete.fasta

### **Creating pacbio\_reads.sam**

```
cat /storage/datasets/Tetrahymena_thermophila/SRX2635099/fastq/*.fastq > pacbio_reads.sam
```

### **Aligning the pacbio reads with minimap2 onto the Tlr\_complete:**

```
/home/jgjohns6/minimap2-2.12_x64-linux/minimap2 -a  
/storage/datasets/Tetrahymena_thermophila/analyses/virus/data/Tlr_complete.fasta  
/home/jgjohns6/Pacbio_reads.fastq > pacbio_minimap.sam
```

### **Creating sorted bam file from sam file:**

```
samtools view -bS pacbio_minimap.sam | samtools sort -> pacbio_minimap_sorted.bam
```

### **Create index for bam file in order to filter:**

```
samtools index pacbio_minimap_sorted.bam pacbio_minimap_ultra_sorted.bam.bai
```

### **Filter by AF45 chromosome:**

```
samtools view -h -b pacbio_minimap_ultra_sorted.bam AF451863.1 > pacbio_mm_uAF45.bam
```

### **Filter by sam flag 3852 and mapping quality 3:**

```
samtools view -h -F3852 -q10 pacbio_minimap_sorted.bam > Pacbio_mm_uAF45_3852_3.bam
```

### **Creating coverage file from bam file:**

```
samtools depth pacbio_mm_uAF45_3852_3.bam > pacbio_mm_uAF45_3852_3.coverage
```

### **Creating coverage histogram:**

```
import pandas as pd  
import matplotlib.pyplot as plt  
import scipy  
import numpy as np  
df=pd.read_csv("pacbio_mm_uAF45_3852_3.coverage",header=None, sep="\t", names=['contig',  
'position', 'depth'])  
#print(df)  
df.plot(x='position', y='depth')  
plt.show()
```

