

Tetrahymena Pipeline

Reference Locations:

References

Reference genome of Tlr location:

/storage/datasets/Tetrahymena_thermophila/analyses/virus/data

Mac reference location: /storage/reference_genomes/tetrahymena_thermophila/mac/mac.genome.fasta

Mic reference location:

/storage/reference_genomes/tetrahymena_thermophila/mic/mic.genome.fasta

Illumina:

Sample location: /storage/datasets/Tetrahymena_thermophila/ancestor_ges/fastq

Pacbio:

Pacbio location: /storage/datasets/Tetrahymena_thermophila/SRX2635099/fastq

Combing R1 and R2 for all 40 ancestors: (MAKE BASH SCRIPT IN FOLDER)

Found in: /work/jgjohns6/Tetrahymena/illumina/scripts/Ancestors_R1.sh (and Ancestors_R2.sh)

folder='/storage/datasets/Tetrahymena_thermophila/ancestor_ges/fastq/Anc*'

DIR='Ancestors'

mkdir -p \$DIR

for subfolder in \$folder;

do

oldfilename=\${subfolder##*/}

oldfilename=\${oldfilename}.R2.fastq

#echo \$subfolder "\$DIR/\$subfolder_R2.fastq";

find \$subfolder -name "*R2*" -exec cat {} \; >> "\$DIR/\$oldfilename";

Done

Make ultra-reference using cat command on Mic + Mac + Tlr references and create reference index using bowtie2 build

Ultra-reference found in: /work/jgjohns6/Tetrahymena/illumina/ultra_reference

Referenced from Bowtie2 Manual: <http://bowtie-bio.sourceforge.net/bowtie2/manual.shtml#the-bowtie2-build-indexer>

Aligning Ancestors R1 and R2 individually using bowtie2, reference bash script, ultra_RG.sh:

Found in: /work/jgjohns6/Tetrahymena/illumina/scripts/bowtie2_Anc.sh

bowtie2 --rg-id Anc_10_A -x ultra_reference.index -1 /home/jgjohns6/Ancestors/Anc_10_A-32273406.R1.fastq -2 /home/jgjohns6/Ancestors/Anc_10_A-32273406.R2.fastq -S Anc_10_A_ultra.sam

Run full script in parallel using:

Parallel -j 20 < bowtie2.sh

Merging all 40 ancestor files into one file, Anc_ultra.sam:

Found in /work/jgjohns6/Tetrahymena/illumina/Anc_ultra/Anc_ultra.sam

samtools merge Anc_ultra.sam *.sam

Convert Sam file to Bam file:

Found in /work/jgjohns6/Tetrahymena/illumine/Anc_ultra/Anc_ultra.bam

samtools view -b -o Anc_ultra.bam Anc_ultra.sam

Filter on SAM flag 3852 and mapping quality 10 to create filtered bam file:

SAM flag 3852 filters read unmapped, mate unmapped, not primary alignment, read fails platform/vendor quality checks, read is PCR or optical duplicate, and supplementary alignment. Used this website as reference: <https://broadinstitute.github.io/picard/explain-flags.html>

```
samtools view -h -F3852 -q10 Anc_RG_ultra.bam > Anc_RG_ultra_3852_10.bam
```

Sort bam file

```
Samtools sort Anc_ultra_3852_10.bam > Anc_ultra_3852_10_sorted.bam
```

Create an Index for the bam in order to run the filter:

```
samtools index Anc_RG_ultra.bam Anc_RG_ultra.bai
```

Filter on AF45 (Tlr chromosome)

```
samtools view -h -b Anc_RG_ultra.bam AF451863.1 > Anc_RG_ultra_AF45v2.bam
```

Count Plot:

SAM flag is not actually needed to make count plot, yet is shown in these scripts, count plot is made from RG and header

Convert Bam file back into Sam**Create text file of RG and SAM flag columns using the filtered bam**

```
awk '{for(i=1;i<=NF;i++) if(i==2 || $i~"RG") printf $i" ";print ""}' Anc_ultra_3852_10.sam > Anc_RG_ultra_3852.txt
```

Create a png file on the count plot using the text file

```
import pandas as pd
import matplotlib
matplotlib.use('Agg')
from matplotlib import pyplot as plt
import seaborn as sns
df = pd.read_csv('Anc_ultra_3852_10_AF45.txt', sep=" ", index_col=False, header=None,
names=['Ancestor'], engine='python')
```

```
#df = df.iloc[4:]
#df.head()
#df['Ancestor']
```

```
df = df[~df['Ancestor'].astype(str).str.startswith('VN')]
df = df[~df['Ancestor'].astype(str).str.startswith('SN')]
df = df[~df['Ancestor'].astype(str).str.startswith('ID')]
df = df[~df['Ancestor'].astype(str).str.startswith('ID')]
df = df[df['Ancestor'].astype(str).str.startswith('RG')]
```


```
df['Ancestor_split'] = df['Ancestor'].str.split('.')
```

```

df['Ancestor_split_last'] = df['Ancestor_split'].str[-1]
#print(df)
#df2 = df.iloc[10:]
x = df['Ancestor_split_last'].value_counts()
#print(x)
my_figure = sns.countplot(x='Ancestor_split_last', hue=None, data=df) #no y input needed, counts
occurrences for y axis
plt.xticks(rotation=45)
my_figure.tick_params(labelsize=5)
#my_figure.savefig('Ancestorplot.png')
fig = my_figure.get_figure()
fig.savefig('Ancestorplot_ultra_AF39_3852_3.png')

```

Must download png to home computer to view, hines does not allowing viewing of images



Coverage Histogram

Create coverage file of filtered bam

```
samtools depth deduped_MA605.bam > deduped_MA605.coverage
```

Plot Histogram in python

```

import pandas as pd
import matplotlib.pyplot as plt
import scipy
import numpy as np
df=pd.read_csv("ancestralalign_sorted.coverage",header=None, sep="\t", names=['contig', 'position',
'depth'])
print(df)
df.plot(x='position', y='depth')

```

```
plt.show()
```

